

Thank you for purchasing this HOBBYWING product! Brushless power systems can be very dangerous. Any improper use may cause personal injury and damage to the product and related devices. We strongly recommend reading through this user manual before use. Because we have no control over the use, installation, or maintenance of this product, no liability may be assumed for any damages or losses resulting from the use of the product. We do not assume responsibility for any losses caused by unauthorized modifications to our product.

**01 Warnings**

- Ensure all wires and connections are well insulated before connecting the ESC to related devices, as short circuit will damage your ESC.
- Ensure all devices are well connected to prevent poor connection that may cause your multi-rotor to lose control or other unpredictable issues such as damage to the device.
- Read through the manuals of all power devices and ensure the power configuration is rational before using this unit.
- Please use a soldering iron (ensuring it's connect wires and connectors with wire) with the power of at least 60W to solder.
- Stop using the ESC when its casing temperature exceeds 100°C, otherwise your ESC will get destroyed and may also get your motor damaged.
- Please swap any two ESC-to-motor wires if the motor runs in reverse.

**02 Features**

- Special core program for multi-rotor controllers greatly improves throttle response.
- Specially optimized software for excellent compatibility with multi-rotor motors.
- Microprocessor powered by independent DC regulator has better anti-interference performance greatly reduces the risk of losing control.
- Separate signal wires for reminding user of RPM output & error states.
- All settings except the timing are preset, making usage simple, high intelligent and adaptive.
- Compatible with various flight-controller and supports a signal frequency of up to 621Hz.
- DEO (Driving Efficiency Optimization) technology for better throttle linearity and higher driving efficiency.
- PWM frequency of 18KHz.
- Firmware upgrade via HOBBYWING multifunction LCD program box or WIFI module (item sold separately).

**03 Specifications**


Model	Con. C	Peak C (10s)	BEC	LiPo	Programmable Item	Weight	Size (L*W*H)
XRotor Pro-80A-HV-V3-RTF	80A	100A	No	6-14S	DEO (ON/OFF)	118g	86.1*42.0*20.5mm (Length w/o ears)
XRotor Pro-100A-HV-V3-RTF	100A	120A	No	6-14S	DEO (ON/OFF)	134g	86.1*42.0*22.6mm (Length w/o ears)

**04 User Guide**

**Throttle Calibration**

**Attention!** Users need to calibrate the throttle range when they start to use a new XRotor brushless ESC or another transmitter.

**Step 1: Wiring**




**Notes:**


- The tri-color (Black/Red/White) cable is the programming cable.
- The Black wire is the GND wire.
- The bi-color (White/Black) cable is the throttle control cable
- The Yellow wire is the RPM signal output wire.
- The White wire is the signal wire for warning user of error states.

**Step 2: ESC Programming**

**Warning!** This is an extremely powerful brushless motor system. We strongly recommend removing your propellers for your own safety and the safety of others around you before performing calibration with this system.



**05 Normal Start-up Process**



**06 Protections**

This ESC is specially designed for multi-rotors/drones; it has no low-voltage cutoff protection function.

**Start-up Protection:** The ESC will shut down the motor if it fails to start the motor normally within 2 seconds by increasing the throttle value. In this case, you need to move the transmitter throttle stick back to the bottom position and restart the motor. (Possible causes of this problem: poor connection/disconnection between the ESC and motor wires, propellers are blocked, etc.)

**Motor Lock-up Protection:** The ESC will cut off its output and stop trying to restart the motor when it detects the motor is not rotating. The output until you move the throttle stick to the bottom position first and then push the stick upward.

**Over-current Protection:** The ESC will cut off its output immediately when the peak current gets close to 350A (the short-circuit current). It only restarts after you power it off and then back on.

**Throttle Signal Loss Protection:** When the ESC detects loss of signal for over 0.25 second, it will cut off the output immediately to avoid an even greater loss which may be caused by the continuous high-speed rotation of propellers or rotor blades. The ESC will resume the corresponding output after normal signals are received.

**07 Trouble shooting**

Trouble	Warning Tone	Possible Cause	Solution
The ESC was unable to start the motor.	" B, BBB, BBBB ..."	Reverse throttle	Please set the throttle direction to " REV" on the transmitter.
The ESC was unable to start the motor.	" B, B, B ..." (The motor beeped rapidly.)	The throttle stick is not moved to the bottom position or the throttle range is too narrow.	Move the throttle stick to the bottom position or recalibrate the throttle range.
The ESC was unable to start the motor.	" B B-, B-.... " (The interval is 1 second.)	No output signal from the throttle channel on the receiver.	Check if the transmitter and receiver are well bound, if the throttle control cable has been properly plugged into the TH channel on the receiver.
The power-on voltage is below 18V.	" B-BBB-..." (The interval is 1 second.)	The battery voltage is too low.	Change another suitable battery that is fully charged.
The power-on voltage is above 65V.	" B-BBB-..." (The interval is 1 second.)	The battery voltage is too high.	Change another suitable battery that is fully charged.

**Explanations for errors/warnings**

Errors/Warnings	Possible Cause	Solution
	Overheat issue happened to the ESC.	Land the multi-rotor immediately and stop using it until the ESC cools down.
	Over-current issue happened to the ESC.	Stop using the multi-rotor, check if the ESC has the over-current issue.
	The power-on voltage is below 18V.	Change another suitable battery that is fully charged.
	The power-on voltage is above 65V.	Change another suitable battery that is fully charged.